

HyperCore™ GPU Virtualization Manager

FEATURES AND BENEFITS

- Designed as a modular architecture to support a variety of different multicore and multi-partitioned configurations
- Allows sharing of a single GPU, or multiple GPUs, across multiple guest operating systems
- Hypervisor level module has deterministic and bounded execution time
- Efficient GPU management and user defined prioritizations
- Real time watchdog module available to ensure partition integrity and GPU health monitoring
- Minimal CPU overhead
- Implemented without the use of spin locks ensuring deterministic scheduling of user rendering partition
- Supports RTOS, including Wind River VxWorks, SYSGO PikeOS, Green Hills INTEGRITY, DDCI-Deos, Lynx Software MOSAic, Linux and configurable for proprietary RTOS
- Fully integrated with CoreAVI's VkCore® SC (Vulkan) graphics and compute driver, ArgusCore™ (OpenGL) graphics, and DecodeCore® video decode drivers
- Supports use of TrueCore™ GPU health monitoring in dedicated partitions
- Available with CertCore™ 178 (Avionics DO-178C / ED12-C Level A) safety certification packages

INTRODUCTION

CoreAVI's HyperCore GPU Virtualization Manager is designed to enable the virtualization of graphics/video capabilities using one or more graphics processors being utilized by multiple instances of independent partitions or guest operating systems.

HyperCore allows multiple guest operating systems to share a single graphics processor as if they were using it exclusively on their own. This feature allows multiple rendering partitions, on multiple guest operating systems, operating on multiple CPU cores to share a single GPU resource. The HyperCore module allows users to set GPU prioritization and most efficiently virtualize and display graphics/video content on systems deploying an RTOS hypervisor and multicore platforms.




Figure 1: HyperCore GPU Virtualization Manager

The information contained in this document is for informational purposes only and is subject to change without notice. While every precaution has been taken in the preparation of this document, it may contain technical inaccuracies, omissions and typographical errors, and CoreAVI is under no obligation to update or otherwise correct this information. CoreAVI makes no representations or warranties with respect to the accuracy or completeness of the contents of this document, and assumes no liability of any kind, including the implied warranties of non-infringement, merchantability or fitness for particular purposes, with respect to the operation or use of CoreAVI hardware, software or other products described in this document. No license, including implied or arising by estoppel, to any intellectual property rights is granted by this document. Terms and limitations applicable to the purchase or use of CoreAVI's products are as set forth in a signed agreement between the parties. CoreAVI, the CoreAVI tracer logo, VkCore®, ArgusCore™, DecodeCore®, TrueCore™, CertCore™ 178, and combinations thereof are trademarks of CoreAVI. PCIe and PCI Express are registered trademarks of PCI-SIG Corporation. ARM and Cortex are registered trademarks of ARM Limited in the UK and other countries. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

© 2020 Core Avionics & Industrial Inc. All rights reserved.